



TARDIS MANUFACTURING CC t/a

# Advanced Cement

Manufacturers of elegant cemented wall & floor concepts

## Data sheet – Tigtex Cementitious Waterproofing

### Preparation on new concrete surfaces

Ensure walls are dry and plastered for at least 14 days. Remove all loose aggregate and plaster splatters with a scraper. Wet plastered walls with clean water thoroughly before first coat.

### Application method

- Wet walls thoroughly using clean water.
- Mix the Tigtex with clean water into a lump-free, workable slurry.
- Making use of a blockbrush apply the Tigtex liberally in a criss-cross motion onto the wetted area to be waterproofed. Keep stirring to prevent settling. Use the mixture within half an hour. Only mix what you will use.
- Wet the surface after about 12 hours (depending on weather) until moist.
- Apply a second coat in the same manner, with brush strokes across those of the previous coat, if necessary.

### **Super Tanking System for failing plaster:**

- Chop off plaster, apply Tigtex to brickwork.
- Wet the wall before plastering.
- Apply plaster in normal way.
- When plaster is dry, apply Silblock Water Repellent until saturated.
- Apply solvent based Bonding Liquid before painting.

|  |                   |
|--|-------------------|
| Reg Nr: 2014/197853/07   | Vat Nr: Pending   |
| Honeydew Shopping Centre Unit 59, 1 Blueberry Street, Honeydew |                   |
| Unit 7, Pryde Business Park, Broadlands Road, Somerset West    |                   |
| P O Box 230, Honeydew, 2040 email: sales@advancedcement.co.za  |                   |
| Tel: 011 794 2403  | Fax: 086 619 3926 |